


CONFINED SPACE ENTRY PROCEDURES FLOWCHART

Entry precautions: Entrance Covers. Any conditions making it unsafe to remove an entrance cover must be eliminated before the cover is removed. When the entrance covers are removed, the opening must be promptly guarded as necessary to prevent an accidental fall through the opening and to protect the entrants from external hazards.



*if there are any changes in conditions or if any other problems arise, stop work and evacuate space immediately. CSE - Confined Space Entry